

Enabling the Fujitsu Fingerprint Sensor for Login

Fujitsu tablets have a fingerprint sensor which can be used to log into the machine instead of using an ID and password.

Follow the instructions below to enable the fingerprint sensor:

1. Log on initially with Username and Password.
2. Select Start, All Programs.
3. Select Softex.
4. Select OmniPass Control Center.
5. Select User Enrollment.
6. Follow the instructions in the User Enrollment guide.
7. After completing the enrollment process, restart the tablet and wait for login prompt.
8. Swipe finger or thumb to log on.

Enrolling in the fingerprint software does not disable your standard login with ID and password but provides an alternative method of logging into the system.

You can enroll multiple fingers if you wish. You can swipe your finger in either direction.